



# SMASH

Smash is applied to the rubber surface of offset printing blankets to effect a temporary repair of low spots and indentations.

Smash contains a swelling agent which, when applied to the face of the blanket in the damaged areas, will cause the surface to return to its original level, enabling the printer to finish his shift or complete a job without having to lift or change blankets. Smash will not damage the printing surface but it will not repair cuts or any damage where the surface rubber has been destroyed.

## DIRECTIONS FOR USE

Identify and clean the low spot on the blanket. Apply Smash to this area with the brush provided in the cap of the tin. Leave Smash on the blanket for approximately 5 seconds, and then wipe off with a dry cloth. If the swelling recovery is insufficient, repeat steps 2 & 3. After treatment, wipe off the residue to avoid any possible damage to the printing plate.

**Important:** After use, always replace the cap on the Smash tin to minimise evaporation of solvent.

