



ABC 111 WASH

ABC 111 Wash is a highly effective water miscible one-step blanket and roller cleaner containing a blend of solvents & detergents. When used in conjunction with water it will quickly remove gum glaze and lint as well as ink, leaving blankets and rollers with a velvet-smooth ink receptive surface.

ABC 111 Wash is suitable for automatic or manual washing systems and is safe for use on all types of pre sensitised plates

- Suitable for manual or automatic use
- Safe on all types of presensitised metal plates
- Cleans quickly and thoroughly
- Reduces blanket tack
- Prevents oxidation and swelling of the rubber
- Keeps rollers and blankets ink-receptive

DIRECTIONS FOR USE

Manual use

Blankets: Apply ABC 111 Wash either neat or on a water damp cloth. After removing the ink film, wipe away any excess with a dry cloth.

Rollers: Apply in the usual way either neat or mixed with water. For thorough cleaning and removal of gum glaze and lint apply ABC 111 Wash neat and rinse off with water.

Dampers: ABC 111 Wash can be used for either machine or hand washing of dampers. Apply, scrub and rinse clean with water.

Automatic use

Follow manufacturer recommendations

